

## Furling Lines



Are used to adjust the skirt depth to suit the water depth profile and to lower and raise Turbidity Curtain skirts for deployment and retrieval.